

# **INSTRUCTION MANUAL**

## ***1/8th Scale 4WD Nitro Powered Radio Controlled Monster Trucks and Monster ATV***

**A** ☐ *1/8th scale monster truck*



**B** ☐ *1/8th scale monster truck*



**C** ☐ *1/8th scale monster ATV*



### ***Notes:***


- ⇒ Read and understand the instructions carefully before operating or assembling your racing model.***
- ⇒ Specifications are subject to change without prior notice, and actual received model may vary from the images and/or descriptions in this manual.***



A - 1/8TH SCALE MONSTER TRUCK  
Specifications:

Length	Width	Height	Wheelbase	Ground Clearance	Gear Ratio	Wheel track	Diameter Of Wheel	Width Of Wheel
490mm	400mm	260mm	320-330mm	78mm	17.9:1	300mm(F) 305mm(R)	155mm	89mm

- 1.Four wheel drive system
- 2.Double-head assembly lever with reverse teeth
- 3.Steel adjustable central teeth and umbrella teeth
- 4.6061/t6 aluminium anodized radio tray and alum.chassis
- 5.Solid universal joint cups/good quality ball bearings
- 6.Soild wheel rims and large v-tread tyres provide long service period.
- 7.Good qulity plastic parts features high performance.
- 8.Disc brake system provides quick brake response
- 9. Extra large leak proof fuel tank with spring loaded fill cover and a long fuel tube provides quick re-fueling manner.
- 10. 6mm rear anti-roll bar & compact battery/receiver box



Universal Shaft With Aluminium Steering Joint Cup



Leak Proof Fuel Tank With Overflow Pipe



Disc Brake System



Anti Roll Bar and Receiver/Battery Box

B - 1/8TH SCALE MONSTER TRUCK  
Specifications:

Length	Width	Height	Wheelbase	Ground Clearance	Gear Ratio	Wheel track	Diameter Of Wheel	Width Of Wheel
490mm	412mm	260mm	320-330mm	76mm	17.9:1	302mm(F) 306mm(R)	150mm	100mm

- 1.Four wheel drive system
- 2.Double-head assembly lever with reverse teeth
- 3.Steel adjustable central teeth and umbrella teeth
- 4.6061/t6 aluminium anodized radio tray and alum.chassis
- 5.Solid universal joint cups/good quality ball bearings
- 6.Soild wheel rims and extra large aggressive tread tyres provide long service period.
- 7.good qulity plastic parts features high performance.
- 8.Disc brake system provides quick brake response
- 9. Extra large leak proof fuel tank with spring loaded fill cover and a long fuel tube provides quick re-fueling manner.
- 10. 6mm rear anti-roll bar & compact battery/receiver box




C - 1/8TH SCALE MONSTER ATV  
Specifications:

Length	Width	Height	Wheelbase	Ground Clearance	Gear Ratio	Wheel track	Diameter Of Wheel	Width Of Wheel
490mm	396mm	260mm	320-330mm	70mm	17.9:1	296mm(F) 298mm(R)	120mm	82mm

- 1.Four wheel drive system
- 2.Double-head assembly lever with reverse teeth
- 3.Steel adjustable central teeth and umbrella teeth
- 4.6061/t6 aluminium anodized radio tray and alum.chassis
- 5.Solid universal joint cups/good quality ball bearings
- 6.Soild wheel rims and pre-mounted tyres provide long service period.
- 7.Good qulity plastic parts features high performance.
- 8.Disc brake system provides quick brake response
- 9. Extra large leak proof fuel tank with spring loaded fill cover and a long fuel tube provides quick re-fueling manner.
- 10. 6mm rear anti-roll bar & compact battery/receiver box



Body required



1/8th scale monster ATV body




1/8th scale monster ATV body handle




Body handle mount



Two cap head self-tapping screws 2.6\*10



Use two cap head self-tapping screws(2.6\*10) and the handle mount to install the handel to the body.



Install ATV rider with the rider post

Use the clip to lock the mount hole on the post.



The following accessories are for optional purchase to facilitate your operation.



Note: Actual received tools may vary from the images.

## Use the transmitter to control your model

**Installing the batteries to the transmitter**  
The battery door is located on the bottom of the transmitter.

### Notes:


1. In order to keep good performance under operation, we warmly recommend you to use the 1.5V alkaline batteries other than the 1.2V chargeable batteries.
2. The batteries may leak in the event that they are installed with wrong polarities. Do not use batteries of different types. Do not mix the old and fresh batteries.

## The function parts/switches on the transmitter




1. Antenna
2. Throttle Trim
3. steering Trim
4. Crystal
5. Throttle Trigger

6. Power Switch
7. Working Indicator
8. Steering Reverse Switch
9. Throttle Reverse Switch
10. Steering Wheel




### 1. Throttle Trigger

1. Push the trigger forwards to allow the vehicle to speed down or brake.
2. Pull the trigger backwards to allow the vehicle to go forward and speed up.



### 2. Steering Wheel

Turn the steering wheel to the left or right to let the vehicle turn left or right.



### 3. Throttle Trim

Throttle Trim is to trim the throttle servo when the trigger is at Neutral position.

### 4. Steering Trim

Steering Trim is to trim the front wheels steering.  
Note: If the front wheels are not aligned when the trigger is set at Neutral position, please adjust the steering trim to make them aligned.

### 5. Steering/Throttle Reverse Switch


If you are a reverse operator, set the steering/throttle reverse switch to REV. Position first.

## Before running or assembling your car...


The following items (not supplied in this kit unless specified) are required for assembling your vehicle and are available in the local hobby shops. Please read this manual completely before assembling or operating your vehicle.

Note: The engine should be adjusted properly in IDLE mode before operating your vehicle. Otherwise, the life and performance will be affected.

### Additional Items Needed For Running Your Model




### Tools Needed For Assembling Your Model



## 2-Channel Radio Transmitting System

Please read the instructions for the radio system carefully before running your car.

The servo is required to be set at Center position before starting assembly. To set the servo at the Idle (Neutral) position switch on the transmitter and receiver. Allow the servo trim arm at Center position, and turn off the transmitter then the receiver. All debug operations are complete, and the servo is in the Middle position that you expect.






# Pre-Run Check

Please check your model before each driving.


## 1 Transmitter Switches




### Caution!

Make sure the antenna is fixed tightly. Otherwise, the transmitter may be out of control. Please extend the antenna fully when applied.

## 2 Chassis Switch




Turn on the chassis switch.




## 3 Check Steering Performance

Gently lift up the front wheels while adjusting the steering trim.




Operate the steering wheel to check if the front wheels move correctly.



The front wheel movement is controlled by the steering wheel. For instance: If moving the steering wheel to the left, the vehicle front wheels will also turn left.

If the moving direction of the wheel is opposite to above mentioned, please change the Steering Reverse Switch position.


## 4 Steering (Steering Trim Setting)





To permit left and right turning of the front wheels.

Always adjust the steering trim in case that the front wheels fail to remain aligned when the steering wheel is set at Neutral position.


Perform above adjustments again when the vehicle is running.



## 5 Throttle (Throttle Trim Setting)



Remove the air filter sponges.



## ENGINE WORKING

**Carburetor:**  
To measure air and fuel mixture and allow the engine to run properly.

**Glow Plug Igniter:**  
It should be fully charged before use.

**Glow Plug:**  
To ignite the compressed air and fuel mixture.

**Recoil Starter:**  
Pull it to start the engine.

**Low end mixture screw:**  
To measure low end air and fuel mixture


**Idle Adjusting Screw:**  
To adjust engine at Neutral position.

**Needle Valve:**  
To measure high end air and fuel mixture.

The engine includes many high-precision parts. The original performance may be reduced due to incorrect operation and assembly or disassembly.

## Engine Maintenance

1. Empty fuel tank and fuel lines before storing your vehicle.
2. Use premium "After Run Oil" this lubricant is utilised for storing of your engine. Observe manufacturers instructions.
3. Remove all dirt and debris from vehicle with small brush (tooth brush) and/or with compressed air (observe proper personal security when operating air equipment)
4. Inspect and adjust all moving parts for excessive play, if adjustment cannot remove all excessive play observe part integrity and replace if required.
5. Proper lubrication of all bearings and moving mechanism is necessary for proper operation.
6. Disconnect and inspect batteries for leakage, recharge as required, do not store vehicle with batteries in unit for prolonged periods.
7. Operating radio controlled devices in wet/damp conditions is not suggested, vehicle may lose traction abruptly, and vehicle may observe water infiltration in receiver compartment or in servos and loss of control of vehicle is imminent.





## Engine Break In

Many hobby type glow engines require a break in period to provide final adjustment of internal parts after manufacturing. This procedure is required and must be completed by you/the user. To prevent excessive initial wear on internal engine parts a rich air/glow fuel mixture is required to perform your engine break in.

### Very important procedure must be followed !!

Break-in period 2 and 1/2 turns from full closed position (4-5 tanks of 10-15% nitro/20% oil content) must be used to perform break in, do not run engine full throttle for long periods during break-in. Once break-in has been performed lean out engine to best performance (2 turns to 1 and 1/2 turns from full closed position) you must **always** observe a trace amount of oil smoke from tune-pipe, if you do not see any smoke **stop immediately** and re-adjust needle valve till smoke is observed.

Always perform needle valve adjustment first, and then perform idle adjustment on a warmed-up engine. Environment conditions may require further adjustments.

Clean-out engine and exhaust system by applying high throttle (3/4 throttle) for 2 seconds after adjustment to permit effectiveness of adjustment to be observed.

We **highly recommend** replacing the engine "Glow Plug" (part #70117) after you have completed the break-in.


It is of normal occurrence during the break-in that miniscule particles of metal adhere to the glow element. The particles of metal isolate the glow element and affect overall engine performance or short engine service time.

You may also be required to replace your glow plug during your break in procedure.

Normal nitro content: Once break-in has been performed 20% - 35%

Lubrication: We highly recommend a Premium glow fuel with a Synthetic/Castor blend of a minimum of 16% and maximum of 20% combined lubricant content.


## Engine Adjustment



### 1. Needle Valve Adjustment

- Start the engine to run your vehicle.
- Keep an eye on the current running speed when your vehicle is running straight with the throttle control set to High. The speed will go up when you screw in the needle valve at an angle of 10 or 20 degrees.
- When you continue to screw the needle valve further in, the engine may become overheated and even damage. In this case, immediately unscrew the needle valve approx. at an angle of 10 or 20 degrees to cool down the engine and permit the normal running manner.

### Acceleration from idle position.



### 2. High end Adjusting Screw


High end adjusting screw is used to inchingly measure the air and fuel mixture to flow into the carburetor.

### 3. Idle Adjusting Screw


Idle adjusting screw is used to measure the air and fuel mixture to flow into the carburetor when the engine is at Idle position.

## To start the engine


### 1 Fill the fuel tank with fuel




### 2 Switch on the transmitter, then the receiver.



### 3 Remove the air filter.




### 4 Open the throttle fully, and flow 2~3 drops fuel into the carburetor.






## 5 Attach the air filter




## 6 Use the glow plug igniter to excite the engine.



## 7 Hold the car securely pulling the recoil starter cord.


### ⚠ Caution!

► To avoid damage, never force hard to pull the starter cord.




## STOP RUNNING ENGINE

1. Pinch and hold the fuel pipe by a peg or your fingers with the glove to disallow the fuel to flow in.




2. Turn off the receiver then the transmitter.



### ⚠ WARNING

The engine, exhaust manifold and the tune-pipe are hot after running your vehicle and can burn your body. Do not touch any of these components immediately after running. Permit them to cool down before.



## Troubleshooting no-start condition and engine performance.

### Probable causes

### Solutions

The engine is flooded.

Remove glow plug. Crank flooded engine several times to evacuate excess fuel. Do not place yourself over the glow plug hole, fuel may splash or flow when cranking.

## Engine can be cranked but will not start.

Is glow fuel reaching carburetor?

Add 2-3 drops of glow fuel directly in carburetor.

Is idle adjustment set properly?  
Remove air filter to verify.

Adjust opening with screwdriver. (1mm or 0.33")  
Replace air filter before starting.

Verify if glow plug is working.

If element does not glow verify glow stick.  
If in doubt replace glow plug.

## Miscellaneous

Cold outside temperature.

Screw in the needle valve at 60 degrees, and warm up the engine.

Engine is overheating.

Permit engine to cool down then gently unscrew the needle valve at 60 degrees and re-startup the engine.

Carburetor is blocked dirty.

Clean with automotive parts cleaner.

Air filter is blocking air passage.

Clean air filter element or replace air filter element.

Engine performance is affected.

Verify fuel lines, glow plug, adjustments and correct.

## TROUBLESHOOTING LIST

ISSUES	REASONS	SOLUTIONS
THE ENGINE FAILS TO START.	1. The fuel tank is empty or the carburetor is not primed properly. 2. The glow plug is bad or the batteries are dead. 3. The fuel lines, the air filter, or the muffler is clogged. 4. The engine is flooded. 5. The carburetor is not adjusted properly. 6. The servo linkage is not adjusted properly.	1. Fill the fuel tank up or prime the throttle. 2. Replace the glow plug or charge the batteries. 3. Clean or replace the clogged part(s). 4. Remove the glow plug and discharge fuel. 5. Set the Needle Valve/Low End Mixture Screw and the Idle Adjusting Screw to the Original position. 6. Set the servo to Neutral then re-adjust it.
THE ENGINE CAN START BUT STALL IMMEDIATELY.	1. The fuel tank is empty. 2. The fuel lines, the air filter, or the muffler is clogged. 3. The carburetor is not adjusted properly. 4. The engine is flooded.	1. Fill up the fuel tank. 2. Clean or replace the clogged part(s). 3. Re-adjust Idle Adjusting Screw and Needle Valve/Low End Mixture Screw. 4. Allow the engine to thoroughly cool down and turn the Needle Valve open at the angle of 30 degrees.
POOR REACTION RESPONSE ON THE ENGINE.	1. The carburetor is not adjusted properly. 2. Low fuel pressure level was found on the muffler.	1. Re-adjust Needle Valve/Low End Mixture Screw. 2. Install the pressure line from the muffler to the fuel tank correctly.
THE VEHICLE BECOMES DIFFICULT TO CONTROL.	1. The batteries on the transmitter/receiver are weak. 2. Radio antenna performs bad receptions. 3. The servo linkage is not adjusted properly.	1. Replace or charge the batteries. 2. Extend the transmitter antenna fully to obtain better receptions. 3. Set the servo to Neutral then re-adjust it.



*The surface on this truck would never fail to become dirty after used for a long period of time. In order to remain its better performance and prolong the service time, you are required to maintain your truck properly and cleanse it at all times.*



**CLEAN SOLVENTS/TOOLS**  
The following are recommended to clean your truck.

1. Neutral Cleaner
2. Alcohol
3. Lubricants such as WD-40 etc.
4. Cleaning Air Ball
5. Sponge
6. Soft Dry Cloth or Brush

## ■ Cleanse the panel and tyres



Use the neutral cleanser and the soft sponge to cleanse and wipe off dusts on the panel carefully and do not damage the decals on the surface.



The strong cleanser or alcohol is not allowed to clean the inside of the panel. Otherwise, the panel colour may fade. Please use the neutral cleanser.




Use the household sponges or the soft cloth and the brush to clean the tyres.




Check and test the tyres carefully after rough driving. Stick the instant adhesive if the rubbers on it peel away.


## ■ Cleanse the chassis




Use the recommended sprayer to clean the dust on the surface after this model drives a long time.




Use the cleaning spray or the cotton swab or the teeth brush dipped into with little alcohol to clean the spotted place. Spray off water drops with the sprayer after cleaning.



Use the teeth brush to cleanse the dirty corners on the chassis and the linkage or on the shaft as well as on the suspension arms.



Use the teeth brush to cleanse the dirty corners on the chassis or the linkage or the shaft as well as on the suspension arms.



If the air sprayer is not available, you can use the air cleaning ball instead. Always oil the driving parts after cleaning. Otherwise, they may become rusty.

## ■ Engine Detachment and Maintenance



Engine maintenance service is not more difficult than you expected. Flow the maintenance oil into the air inlet. Start the engine by pulling the starter lever, flowing the oil into the engine.



Oil the clutch bearing. Slightly rotate the bearing to have it fully oiled.



Always check the air filter, and clean the air filter when it is dirty. Replace it when it is quite dirty or is not worth cleaning.



Please secure the main body carefully by the lock screws when you attach the parts on it. Always check the parts which are subject to move.



In order to avoid dust getting into the fuel tank, please tight up the screw on it when serving on the engine.



● The servo, the receiver and the batteries should be not immersed into water during running. Dry off the water drops and clean accumulated dusts on the surface as well as oil the parts to avoid getting rusty after running several times.



● The rear wheels will support the total vehicle weight when the truck is going upgrade. In this time, you should allow the truck to go upgrade by one operation. Otherwise, the truck may have difficulties in going upgrade at the second try and subject to slide down or turn over.




● This truck will bump over when running on the rocky ground. At this time you should handle the transmitter gently. Rough and abrupt operations will cause the truck to turn over.




● The front wheels will support the total vehicle weight when the truck is going downgrade. In this time, you should gently operate the transmitter and do not allow the truck to swerve or brake abruptly. Failure to do as will cause the truck to turn over.



























# 21CX ENGINE ASSEMBLY DIAGRAM



S001-Glow Plug  
S002-Screw 4P  
S003-Cylinder Head  
S004-Gasket  
S005-Cylinder Piston  
S006-Piston Pin  
S007-Pin Clip 2p  
S008-Joint Lever  
S009-Engine Main Body  
S010-Carburetor Assembly  
S011-Carburetor Bolt  
S012-Screw  
S013-Nut  
S014-Roller Bearing(front)  
S015-Roller Bearing(rear)  
S016-O-Ring  
S017-Crankshaft  
S018-One-Way Clutch Unit  
S019-Gasket  
S020-Engine Backhousing  
S021-Screw  
S022-Pulling Starter  
S023-Screw




## Monster Truck/Monster ATV Parts-1

























81001-Centre Diff. Plate 	81002-Rear Shock Absorber 2P 	81003-Front Shock Absorber 2P 	81004-Rear Drive Dogbones 2P 
81005-Centre Drive Dogbones (front+rear) 	81006-Rear Shock Tower 	81007-Front Shock Tower 	81008-Front Upper Steering Plate 
81009-Radio Tray 	81010-Steering Ackerman Plate 	81011-Wheel Hub+Hex. 2P 	81012-Exhaust Pipe Spring 3P 
81013-Body Clip 6P 	81014-Battery/receiver Case Clip 6P 	81015-Brake Cam 	81016-Differentials Housing+Shim 
81018-Diff. Universal Joint Cup 2P 	81021-Drive Universal Joint Cup 2P 	81022-Steering Hubs 	81023-Universal Drive Dogbone 2P 
81024-Clutch Shoe /Springs 	81025-Drive Pinion Complete 2P 	81026-Main Gear 	81027- Brake& Throttle Assembly 



## Monster Truck/Monster ATV Parts-2

























81028-Brake Disc 4P 	81029-Fuel Tank 	81030-Shock Shafts +Nuts 	81031-Rear Roll Bar+Mounts+Holders 
81032-Lower Arm Shafts+E-Clips 	81033-Chassis 	81041-Fuel Pipe 2P 	81042-Pinions+Spider Gears 
81043-Air Filter Assembly+Zip Ties 	81044-Filter Foam 4P 	81046-Engine Bottom Pads (Alum.) 	81047-Engine Mounts (Alum.) 
81048-Front/Rear Reinforcement Brace 	81049-Switch Cover 2P 	81050-Centre Diff. Mount 	81053-Rear Upright 2P 
81054-Front Bumper 	81055-Battery/receiver Box 	81056-Rear Lower Sus.Arm 2P 	81057-Gear Box 
81058-Front/rear Lower Sus.Arm Holder 	81059-Shock Absorber Cap 8P 	81060-Front Lower Sus.Arm 2P 	81062-Steering Posts + Mount 

## Monster Truck/Monster ATV Parts-3









81063-Steering Assembly 	81064-Front Upper Sus.Arm 2P 	81065-Radio Tray Post +Mounts 	81066-Front/rear Reinforcement Link 
81068-Rear Upper Sus.Arm 2P 	81069-Washers Complete 	81070-Bearings Complete (10*5*4) & (16*8*5) 	81071-Exhaust Pipe Mount +Spring 
81072-PinionGear Joint Cup 	81082-Exhaust Pipe +Spring 	81201-Shock Ball Holder 2P 	81202-Clutch Shoe (Metal) 
81205-Shock Boot 4P 	81207-Universal Joint Ball 3P 	81208-Rear Upper Arm Ball 3P 	81209-Steering Ball 4P 
81210-Shock Ball 6P 	81211-Front Lower Arm Axles 4P +Springs 	81212-Rotary Table Nuts 	81213-Axles 8P 
81222-Clutch Springs 	83001-Centre Diff. Universal Cups 	83002-Centre Diff. Gear 	83003-Clutch Bell (10T) 



Monster Truck/Monster ATV Parts-4

83008-Clutch Bell (10T) 	83009-Body Brace 2P +Body Post 4P 	02057-Antenna Pipe 4P 	83013-Flywheel(Al.) 
83014-Ni-MH Battery (1100mA) 	83016-Receiver 	83018-Gear(49T) 	81220-1 Countersunk Self-tapping screw 3*10 10P 
81220-2 Countersunk screw 3*6 8P 	81220-3 Countersunk screw 3*10 4P 	81220-4 Countersunkscrew 3*12 4P 	81220-5 Countersunk screw 3*14 4P 
81220-6 Countersunkscrew 3*16 4P 	81220-7 Countersunk screw 3*18 4P 	81220-8 Countersunk self-tapping screw 4*20 10P 	81220-9 Countersunk self-tapping screw 4*25 4P 
81220-10 Countersunk Hex. screw 4*20 8P 	81220-11 Countersunk screw 4*6 8P 	81220-12 Countersunk screw 4*10 8P 	81220-13 Cap head self-tapping screw 3*10 13P 
81220-14 Cap head self-tapping screw 3*12 8P 	81220-15 Cap head self-tapping screw 3*16 8P 	81220-16 Cap head self-tapping screw 4*14 4P 	81220-17 Cap head self-tapping screw 4*25 6P 

Monster Truck/Monster ATV Parts-5

81220-18 Cap head screw 3*14 6P 	81220-19 Cap head screw 4*12 5P 	81220-20 Cap head screw 4*10 9P 	81220-21 Cap head screw 4*20 6P 
81220-22 Cap head Hex. screw 3*14 4P 	81220-23 Column head Hex. Screw 3*20 6P 	81220-24 Column head Hex. Screw 3*14 4P 	81220-25 Column head Hex. Screw 3*25 4P 











The parts above illustrated are completely for (A) monster truck, (B) monster truck, and (C) monster ATV.

The following parts are separately in use for (A) monster truck, (B) monster truck or (C) monster ATV.

83004-Tyre 2P  For(A)Monster Truck	83005-Wheel Complete 2P  For(A)Monster Truck	83006-Wheel Rim 2P  For(A)Monster Truck	89104-Tyre 2P  For(B)Monster Truck
89105-Wheel Complete 2P  For(B)Monster Truck	89106-Wheel Rim 2P  For(B)Monster Truck	86701-Wheel Rim 2P  For(C)Monster ATV	86721-Tyre 2P  For(C)Monster ATV
86722-Wheel Complete 2P  For(C)Monster ATV	ATV801-1/8th scale monster ATV body  For(C)Monster ATV	ATV802-1/8th scale monster ATV body handle with mount and screws  For(C)Monster ATV	ATV803-1/8th scale monster ATV rider w/the mount post  For(C)Monster ATV




# Monster Truck/Monster ATV Optional Upgradable Parts

<p>81603-Rear Shock Tower(Al.)</p> 	<p>81604-Front Upper Arm Holder(Al.)</p> 	<p>81605-Rear Upper Arm Holder(Al.)</p> 	<p>81608-Rear Upper Adjustable Arms (Al.)</p> 
<p>81609-Front Upper Adjustable Arms (Al.)</p> 	<p>81610-Rear Uprights</p> 	<p>81613-Rear Lower Arms</p> 	<p>81614-Steering Plate</p> 
<p>81615-Upper Deck</p> 	<p>83012-Engine (Japan 27CXP&amp;Taiwan28CXP)</p> 	<p>81084-1/8 28cpx Exhaust Pipe</p> 	<p>81202-Clutch Shoe (Alum.)</p> 

*Optional parts are subject to change and we may add more upgradable items in this list.*



# Exploded Diagram



## Wheels and Tyres Required For (A) Monster Truck

83004-Tyre  For(A)Monster Truck	83005-Wheel Complete  For(A)Monster Truck	83006-Wheel Rim  For(A)Monster Truck
--	--	---

## Wheels and Tyres Required For (B) Monster Truck

89105-Wheel Complete  For(B)Monster Truck	89106-Wheel Rim  For(B)Monster Truck	89104-Tyre  For(B)Monster Truck
--	---	--

## Wheels and Tyres Required For (C) Monster ATV

86701-Wheel Rim  For(C)Monster ATV	86721-Tyre  For(C)Monster ATV	86722-Wheel Complete  For(C)Monster ATV
---	--	--